

Good-bye
Dishwashing Drudgery



MANVILLE

DISHMASTER

COMBINES:

1. Modern Mixing Faucet
2. Swing Spout
3. Vegetable Sprayer
4. Dishwasher

DISHMASTER

*... washes each dish
in fresh, clean suds*



*... rinses each dish
in clear, aerated,
hot water!*


AND ONLY

\$39.50



WALL TYPE OR TABLE TYPE QUICKLY, EASILY INSTALLED

PATENTS PENDING



"NO FUSS .. NO MUSS ..
NO BOTHER AT ALL!"



You'll find doing dishes the Dishmaster way is almost like not doing dishes at all! It's so easy . . . as simple as turning on a faucet! So practical . . . you don't soak your hands in steaming hot water, you hardly get them wet! So economical . . . requires far less washing powder! What is Dishmaster? It's the all new modern kitchen sink fixture that lets you spray each dish with fresh, clean suds . . . rubs them, scrubs them, scrapes them . . . then rinses each dish in a bubbling, splashless shower of clear, hot aerated water . . . and all by instant finger-tip control!


No dishpan required . . . and no more "dish-pan" hands! No dishcloths or scouring pads needed because Dishmaster does the work . . .



Smartly styled by
George W. Walker

... all the work in one quick, easy, effortless operation. No drying towels necessary, either. Just "rack" your dishes after a Dishmaster treatment and watch them dry sparkling, spotlessly clean without wiping!

IT'S MUCH MORE SANITARY . . . AND MUCH, MUCH FASTER DOING DISHES THE DISHMASTER WAY!






Easy TO USE

... as simple as turning on a faucet!

Just remove the cover to the Dishmaster tank, pour in 1 or 2 tablespoonfuls of any well-known *detergent* . . . Glim, Vel, Dreft, Tide, Chat, etc. . . . then fill the tank with water. (Caution: Don't use soap flakes, powder, or granules.)

Next, turn on the hot water. It'll flow first through the smart swing spout but, when you lift the diverter valve on top, it comes bubbling out of the Dishmaster Sprayer in a soft, splashless, aerated shower.

Now press the red button on the sprayer handle and . . . PRESTO! . . . out tumbles all the rich, fresh, foamy suds you need to wash each dish sparkling clean. To rinse, release the button . . . and DISHMASTER switches to a gentle shower of clear hot water. "Rack" your dishes as you do them . . . they'll dry spotlessly clean without wiping!



Replace your sink
faucets with a new
DISHMASTER

KISS them
all goodbye!



DISHMASTER *Eliminates:*

Dishpans and "dishpan" hands.
Dishcloths, scouring pads, and
drying towels.

Hard rubbing, hard scraping.
Doing dishes in dirty, greasy
water, getting them only half
clean.

DISTRIBUTOR
SIGWALD ENGINEERING CO.
2007 - 4th AVENUE SO.
MINNEAPOLIS 8, MINN.
RE. 8201

GERITY-MICHIGAN CORP.
ADRIAN, MICHIGAN

G.P.

Printed in U.S.A.